

Installation Instructions

Lower Trim Kit For Drop-In Ranges

Tools Required:

#2 Phillips screw driver
Drill with 1/8" Bit

Parts Supplied

Trim Panel
4 screws

This Kit is intended to be supplied for New Drop-In Ranges (JD966 and JDP46) or applications replacing Drop-In Ranges JDP36XXXXX, JDP39XXXXX, JDP46XXXXX, and JDS26XXXXX or other deep cutout Drop-In Ranges.

A Installing the Kit

Prior to installing the Drop-In Range, this kit should be installed:

- A1** Locate the lower trim panel in the cabinets at the bottom of the opening, making sure that its location does not enter the 27 1/4" space required for the range.
- A2** Align the front of the supplied panel with the front edge of the cabinets. Mark the location of the 4 slots and drill 4- 1/8" Dia. pilot holes.
- A3** Align the panel flush with the front surface of the cabinets and tighten the screws in the pilot holes.
- A4** Follow the Installation Instruction for the Drop-In Range to complete the installation.

