

# **GE Monogram Custom Panel Templates Model # ZIW30GNDII, ZIK30GNDII**

**CALL 1-800-626-2000**

**For a full-size panel template with complete panel installation instructions.**

## **Glass Door Template**

31-46543 (A)

197D8240P002

## **Freezer Drawer Template**

31-46543 (C)

197D8240P003


## **Customizable Drawer Template**

31-46543 (D)

197D8240P004



imagination at work



**Top of 80" Panel**  
 84" Panel will extend above this template

0.200" Routing

0.350" Routing

MAX WINDOW OPENING

Routing is required in shaded areas only

Directions For Using Templates:

1. Align template bottom with bottom of door/drawer panel.
2. Tape the template to the door/drawer panel.
3. Drill all of the 0.125" pilot holes.
4. Using a marker, go along all of the perforated edges to trace the routings.
5. Remove the template from the panel.
6. Route the marked areas to the depth indicated on the templates.
7. Max window opening is 33-3/8" x 23". Window opening may be smaller if desired.
8. Wood panels must be at least 3/4" thick at hook and bracket locations.
9. 0.350" routing needs to extend to edge of window opening.

6.0"  
 ART IS CORRECT IN SIZE AND SCALE WHEN  
 LINE LENGTH IS CORRECT

**Glass Door Template  
 Custom Panel**

Pilot holes 0.125" diameter, 0.300" depth

**Warning:** Before drilling holes for brackets, please make sure they do not line up with thin areas on the panel.

31-46543-1 (A)  
 197D8240P001

