## RAS300DMWW


Hotpoint<sup>®</sup> 24" Free-Standing Front-Control Electric Range

### DIMENSIONS AND INSTALLATION INFORMATION (IN INCHES)


#### **RECEPTACLE LOCATIONS**

Locally approved flexible service cord or conduit must be used because terminals are not accessible after range installation. See shaded area in drawings for location of electrical outlet box. Recommended outlet locations allow range to be installed directly against rear wall.

TING
9.3
7.2



### DIMENSIONS AND CLEARANCES (CONT.) ELECTRICAL OUTLET LOCATIONS





All GE Appliances ranges are equipped with an Anti-Tip device. The installation of this device is an important, required step in the installation of the range.

## **Hotpoint**.

For answers to your Hotpoint product questions, visit our website at hotpoint.com or call 800.626.2000.

### RAS300DMWW

Hotpoint<sup>®</sup> 24" Free-Standing Front-Control Electric Range

#### **FEATURES AND BENEFITS**

Front controls - Minimize need to reach

Sensi-Temp Technology – Enjoy the same cooking power as a traditional coil with an added safety feature that meets new UL858 Household Electric Ranges Standard for Safety

Lift-up cooktop with porcelain-enameled subtop – Access messes under the cooktop for easy cleanability

Two oven racks - Durable to securely hold any cookware

Standard clean oven - Smooth surface makes cleaning by hand easier

One-piece durable handle – Strong and long-lasting


Chrome drip bowls - Contain spills and remove for easy cleaning

Standard window – Provides a convenient viewing area to check the progress of food

Cooktop "On" Indicator Light - Know when an element is on

Storage drawer - Ideal for cookware and kitchen accessories

Model RAS300DMWW - White



# Hotpoint.