

# PVW1030SWSS

## GE® Profile 30" Wall Mount Range Hood with Clean Air Sensing

### DIMENSIONS AND INSTALLATION INFORMATION (IN INCHES)

**INSTALLATION INFORMATION:** Before installing, consult Use & Care/installation instructions packed with product for current dimensional data.



#### INCLUDED ACCESSORIES

Non-return Damper (8" round)  
Grease Filters – 2 X Baffle

#### OPTIONAL ACCESSORIES

PX8DC1SWSS – 8(ft.) High Ceiling Duct Cover Kit  
PX12DC1SWSS – 12(ft.) High Ceiling Duct Cover Kit  
UXCN36W – Recirculation Kit (includes Charcoal Filter)  
UXCF91 – Charcoal Filter (needed if used in recirculation mode)

AMP RATING	
120V	2.8



The vent hood must be installed 24" min. above the cooking surface. For optimal performance, installing the hood more than 36" above the cooking surface is not recommended. The hood installation height above the cooking surface depends upon the ceiling height. The telescopic duct cover conceals the ductwork running from the top of the hood to the ceiling.

**NOTE:** Installation height should be measured from the cooking surface to the lowest part of the hood. This hood may be installed onto a wall and vented to the outdoors, or it can be installed for recirculating operation. Recirculating parts are supplied separately as optional accessories.



For answers to your Monogram, Café™, GE Profile™ or GE Appliances product questions, visit our website at [geappliances.com](http://geappliances.com) or call GE Answer Center® Service, 800.626.2000.



Specification Revised 7/24

# PVW1030SWSS

## GE® Profile 30" Wall Mount Range Hood with Clean Air Sensing

### FEATURES AND BENEFITS

**Built-in Indoor Air Quality Sensors** – Detects PM 1, 2.5, 4 & 10, volatile organic compounds (VOCs), humidity, and temperature

**Adjustable 610 CFM Range Hood Blower** – Effectively removes smoke, cooking fumes, and odors from the air, keeping your kitchen fresh and clean

**Built-in WiFi** – Operate your smart range hood from your phone, for the ultimate in-kitchen experience

**Chef Connect** – Synchronize your oven and kitchen hood so that it turns on whenever the cooktop is activated, and the lights illuminate when any burner is in use

**Backlit Push Button Controls** – Easily operate your range hood with push buttons that are illuminated from behind, making them easy to locate and use, even in low-light

**4-Speed Fan** – Customize to suit your cooking techniques. Whether simmering or searing, your cooking environment stays comfortable

**LED Hood Light** – Provides a clear view of your cooktop while cooking

**Convertible Venting Options** – Select recirculating or external venting

