

Assembly Instructions

Warming Drawer Pan Kit


For use with 27" and 30" wide warming drawers

JXPN1
Accessory

This kit contains supports and pans to fit your new Warming Drawer.

This kit is designed to fit both 27" and 30" wide models. Select the parts for your model and discard the parts that do not fit.


Parts Included




One Full size pan with Lid, 21" long x 13" wide x 4" deep

Two Half Size Pans with Lids, 21" long x 6-1/2" wide x 4" deep


Two Quarter Size Pans with Lids, 10-1/2" long x 6-1/2" wide x 4" deep




Two sets of Side to Side Support Rails
(one set for 27" and one for 30" wide models)



1. Remove the packaging and separate parts.
2. Open the drawer fully.
3. Select the side to side rails to fit your model.
4. Drop a side to side rail (with slots in the top) into the slots at the rear and one in the front of the drawer. Note that slots fit only one way, with the wide interlocking tabs on the right sides.
5. Drop filler panel into the right side.



6. Drop one or two front to back rails into matching slots.



(continued)

7. Arrange pans to suit food storage needs.
8. Discard the Side to side rails and filler panel not used.

Important Notes:

- Use the pan lids to keep foods moist.
- Do not use plastic wrap! Plastic wrap could melt and damage the interior of your warming drawer.
- Do not place water in the bottom of the warming drawer pan. Moisture can form on cabinets or drip below.

Combinations with full size pan Combinations without full size pan.

