



WATER FILTER CARTRIDGE

⚠ WARNING

To reduce the risk associated with choking, do not allow children under 3 years of age to have access to small parts during the installation of this product. The disposable filter cartridge should be replaced every 6 months at the rated capacity, or sooner if a noticeable reduction in flow rate occurs.

If you have questions, or to order additional filter cartridges, please contact Culligan@fridgefiltersupport.com
